


Midline 90T Treadmill


General Assembly


90T-XXXX-01
S/N TTA100000




Operation Manual	M051-00K60-A028
Service Manual	M051-00K60-A023

Console Assembly		Overlay Bezel	
AK60-00112-0001	Eng/Met	AK60-00109-0001	Eng/Met
AK60-00112-0003	Ger/Met	AK60-00109-0003	Ger/Met
AK60-00112-0004	Spn/Met	AK60-00109-0004	Spn/Met
AK60-00112-0006	Jap/Met	AK60-00109-0006	Jap/Met
AK60-00112-0007	Frn/Met	AK60-00109-0007	Frn/Met
AK60-00112-0008	Itl/Met	AK60-00109-0008	Itl/Met
AK60-00112-0009	Dut/Met	AK60-00109-0009	Dut/Met
AK60-00112-0010	Por/Met	AK60-00109-0010	Por/Met








Left Wire Cover
OK60-01041-0003

Right Wire Cover
OK60-01041-0004



Rear Decal
OK60-01176-0000

Phillips Screw(9)
0017-00101-1288


Console Rear Case
OK60-01072-0001


Midline 90T Treadmill


Motor Cover, Leveler, and End Caps

90T-XXXX-01

S/N TTA100000







Midline 90T Treadmill


Belt, Deck, and Rollers



90T-XXXX-01
S/N TTA100000


Striding Belt

OK60-01024-0000 (All International)

OK60-01024-0002 (Only 90T-0100-01 and 90T-0300-01)







Wheel Assembly
OK60-01020-0000
Cap
OK60-01092-0000
Cotter Pin
0017-00007-0208
Clevis Pin
0017-00007-0270

Lift Frame Assembly
AK60-00065-0000

Midline 90T Treadmill
Lift Motor and Home Switch

90T-XXXX-01
S/N TTA100000

Lift Motor

OK60-01094-0000 (120v)

OK60-01166-0000(220v/60Hz)

Clevis Pins


0017-00007-0214


Clevis Clips

0017-00007-0208


Home Switch



0017-00032-0195






(Not Applicable for Models: 90T-0100-01 and 90T-0300-01)










Midline 90T Treadmill
DC Controller and ON/OFF Switch

90T-XXXX-01
S/N TTA100000



Midline 90T Treadmill
Line Filter Assembly and Line Cord

90T-XXXX-01
S/N TTA100000



90T-XXXX-01
S/N TTA100000

